


APPLICATION: Lifting heavy-duty tire and wheel assemblies from a flat to an upright position.

K-1353 Parts List and Assembly Instructions:


The K-1353 consists of:

1 Main Tube	1 Wheel Hook
2 Front Pivot Bracket	1 Handle
2 Rear Pivot Bracket	8 Button Head Cap Screw
1 Wheel Hook Tube	8 Locknut

1. Assemble the Front and Rear Pivot Brackets to the Main Tube with 4 Button Head Cap Screws and Locknuts. Note the orientation of the beveled ends of the Main Tube when attaching the brackets.




2. Install the Wheel Hook Tube between the Front Pivot Brackets and secure with a Button Head Cap Screw and Locknut. Make sure the tube can rotate without binding.
3. Attach the Wheel Hook to the Wheel Hook Tube with 2 Button Head Cap Screws and Locknuts. The heads of the screws should be tightened against the Wheel Hook.
4. Install the Handle between the Rear Pivot Brackets and secure with a Button Head Cap Screw and Locknut. Note the orientation of the Handle. Make sure the Handle rotates without binding.



Instructions for Use:

1. Open the Wheel Hook by rotating it until it stops against the end of the Main Tube.
2. Open the Handle by rotating it until it stops against the end of the Main Tube.



3. Engage the Wheel Hook under the outside of the tire. With the tool on the centerline of the tire, place the heel of the Rear Pivot Brackets on the opposite sidewall. Place one foot on the tire near the Pivot Brackets and pull back on the handle until the tire rotates to a vertical position.



CAUTION: AVOID POSSIBLE PINCH POINTS. DO NOT CLOSE THE HOOK WITH YOUR FINGERS BETWEEN THE HOOK AND MAIN TUBE. DO NOT CLOSE THE HANDLE WITH YOUR FINGERS BETWEEN THE HANDLE AND MAIN TUBE.

4. Remove the tool from the tire. Rotate the Wheel Hook until it is closed. Then, rotate the Handle closed. A hole in one of the Front Pivot Brackets is provided for hanging the tool.

